BK RESOURCES
888-310-4393 | www.bk-resources.com

SetPro™ Parts & Hardware



BKGCS-SCREW
Washer Head Machine Screws x 8
(4-screws per SetPro™)



BKGCS-ANCHORS
Drop-in Anchors x 8
(4-anchors per SetPro™)

PARTS:
BKG-CS - SetPro™ (2) Two Caster Stops

HARDWARE:
BKGCS-SCREW - (8) Eight Washer Head Machine Screws, BKGCS-ANCHORS - (8) Eight Drop-In Anchors,

TOOLS NEEDED:
Hammer, Hammer Drill, 3/8" Drill Bit, Small Punch



BKG-CS
SetPro™ (Caster Stops) x 2

SetPro™ Installation Instructions

STEP 1. Thoroughly clean the area where the SetPro™ caster stop will be mounted to the floor.

STEP 2. Locate proper placement location of your SetPro™ caster stop and mark the mounting hole locations.

STEP 3. Drill 3/8" diameter by 1" deep holes for the anchors, then use a hammer to tap them into place until they are level with the floor. Use a punch to set the anchors in place.

STEP 4. Set the SetPro™ in place and mount each one down with the mounting screws provided.

SetProInstructions